

## Code instellen (NL)

Dit slot (1) kan tot 90 graden kantelen en kan uitsluitend gedraaid worden wanneer het in de vergrendelde stand staat. De code kan worden gewijzigd, ook wanneer het slot gemonteerd is. De standaard meegeleverde code is 000, maar deze kan worden aangepast door een pin in het gat (2) aan de onderkant van het slot te drukken. Houd de pin ingedrukt terwijl je de gewenste code instelt, en laat de pin los om de nieuwe code te activeren. Het is belangrijk om te benadrukken dat het instellen van een nieuwe code alleen mogelijk is als je al over de oude code beschikt.

## Set Code (ENG)

This lock (1) can tilt up to 90 degrees and can only be rotated when it is in the locked position. The code can be changed even when the lock is mounted. The default code supplied is 000, but this can be changed by pressing a pin into the hole (2) at the bottom of the lock. Press and hold the pin while you set the desired code, then release the pin to activate the new code. It is important to emphasize that setting a new code is only possible if you already have the old code.



(1)



(2)



[www.chargervault.nl](http://www.chargervault.nl)



[www.verhoefinnovations.com](http://www.verhoefinnovations.com)